RECIPE For Interior Walls

Recipe for base coat on interior walls:

Solve	300g	Cellulose Glue K 300 (63600) in 10 quarts cold water overnight.
Add	7 kg	Chalk from Champagne (58000) and
	4 kg	Titanium White Color Concentrate (27000)
		(you can also substitute Titanium White (46200) dry pigment)

mix well.
Pour through a sieve/strainer if necessary.

Add	2 qt.	Primal AC 35 (75100) for greater permanence.

Covers approx. 150 square yards.

Adding 500 g fine Glass Beads (e.g. 59831) creates an additional nice effect.

Recipe for color washes on interior walls:

Solve	100g	Klucel EF (63700) in 10 quarts cold water.
Add	50–250 g	earth pigment according to the desired color intensity.
Mix	½ -1 qt.	Primal AC 35 (75100) acrylic dispersion for greater permanence.

Apply with a flat, wide brush or sponge.

Covers approx. 200 square yards.

Dr. Georg Kremer, Dipl.-Chemiker, Farbmühle, DE-88317 Aichstetten/Allgäu, Phone +49-7565-91120, Fax +49-7565-1606
kremer-pigmente@t-online.de, www.kremer-pigmente.com